## **Gripper Pivot Post Kit Instructions**

1. (Optional) Wedge open gripper with any available item (2.5 - 3.5 inches).



- 2. Remove current pivot.
  - a. Remove thumb screw and nut.
  - b. Push pivot in and rotate 45° to lock it in the compressed position.



c. Remove C-clip with small flat blade screw driver.



d. Turn pivot back to vertical and remove.

- 3. Install new pivot.
  - a. Place spring over pivot post.



b. Insert pivot into gripper. Push and rotate to lock it in the compressed position.



c. Position the C-clip next to the post. Use your thumb to press it into place on the pivot post.



d. Re-install the thumb screw and nut.

Dango-Design.com